


TONE ENCODER MICROPHONE I C-HM8

INSTRUCTION MANUAL




I. INSTRODUCTION


Congratulations on the purchase of the IC-HM8 Tone Encoder Microphone. The IC-HM8 is equipped with a microphone unit and tone encoder unit in a single convenient housing, with curl cord and microphone connector. The tone encoder unit, that consists of a highly accurate IC for the tone generator, requires no frequency adjustment.

Power for the IC, tone generator, is supplied from the transceiver through the microphone cord. The IC-HM8 can be connected direct to ICOM Transceivers, Models IC-255A, IC-260A, IC-251A, etc. that have 8-pin microphone connectors. For the operation with other transceivers, refer to the drawing.

II. METHOD OF USE

- (1) Connect the IC-HM8 to the microphone connector of your transceiver firmly.
- (2) Slide to power on the switch in the key board.
- (3) Push the PTT (Push to Talk) switch and transmit on the frequency you will operate. Then, touch the keys to transmit your code number to open repeaters.





ICOM INCORPORATED