

## The various models and the used boards

	<b>FT-101ZD MK0</b>	<b>FT-101ZD MK1</b>	<b>FT-101ZD MK2</b>	<b>FT-101ZD MK3</b>
<b>Sn#</b>	01 – 07xxxx	08 – 16xxxx	17 – 23xxxx	24 – upxxxx
RF board	PB1960A	PB1960A	PB2154	PB2154
NB/Fix	PB1961B	PB1961B	PB1961B	PB1961B
Premix	PB1962A	PB1962A	PB2152	PB2152
IF	PB1963B	PB1963C	PB1963C	PB1963C
AF	PB1964A	PB1964A	PB1964A	PB1964A
Premix LO	PB1965	PB1965	PB2153	PB2153
Sel.switch	PB1966C	PB1966C	PB1966C	PB1966C
VFO	PB1440B-3420	PB1440B-3420	PB1440B-3420	PB1440B-3420
Rect A	PB1967	PB1967	PB1967	PB1967
Rect B	PB1968A	PB1968A	PB1968A	PB1968A
Capacitor	PB1969A	PB1969A	PB1969A	PB1969A
Trimmer A	PB1970	PB1970	PB1970	PB2193B
Trimmer B	PB1970	PB1970	PB1970	PB2192B
Trimmer C	PB1092	PB1092	PB1092	PB1092
Bandwidth	PB1972	PB1972	PB1972	-
APF	-	-	-	PB2217
Driver	PB1714A	PB1714A	PB1714A	PB1714A
Final	PB1715A	PB1715A	PB1715A	PB1715A
Clarifier	PB1973A	PB1973A	PB1973A	PB1973A
LED	PB1974A	PB1974A	PB1974A	PB1974A
Lever switch	PB1975A	PB1975A	PB1975A	PB1975A
Display	PB1978	PB1978 (*)	PB2098A	PB2098A
Decoder	PB1979	PB1979 (*)	-	-
Counter	PB1980	PB1980 (*)	PB2086A	PB2086A
AM (**)	-	PB2040	PB2040	PB2040
FM (**)	-	-	-	PB2218

(\*) only production numbers starting 16xxxx had the PB2086A counter  
 (\*\* optional, the AM board, or the FM board can be installed (MK3 only).