



**MODEL 2706**

**CITIZENS TWO-WAY RADIO**

**mobile**

**Manufactured and Distributed by  
Hy-Gain de Puerto Rico, Inc.  
P.O. Box 68 State Hwy. 31, Km. 4.0  
Naguabo, Puerto Rico 00718**

EO-2706-A-100



First Printing, April, 1977  
Original Edition, April, 1977

# TABLE OF CONTENTS

	<b>page</b>
<b>CHAPTER 1 - GENERAL INFORMATION</b>	
Introduction .....	1
General Description .....	1
Warranty Service Department .....	1
How to Ship Returns .....	1
Purchase of Parts .....	2
Specifications .....	2
<b>CHAPTER 2 - THEORY OF OPERATION</b>	
General .....	5
Phase Locked Loop Frequency Synthesizer .....	5
CB Receiver .....	6
Monitor Receiver .....	6
Monitor Channel .....	9
Transmitter .....	9
Noise Blanking Circuit .....	10
Transmitter Lamp Circuit .....	10
PA Amplifier and Switch .....	10
<b>CHAPTER 3 - ALIGNMENT</b>	
General .....	11
Recommended Tools and Equipment .....	11
Transmitter Alignment Procedure .....	11
Equipment Set-up .....	11
Pre-Alignment Frequency Check .....	12
VCO Circuit Alignment .....	12
RF Driver Stage Alignment .....	12
RF Power Amplifier Alignment .....	13
Transmitter Frequency Check .....	13
Modulation Sensitivity Alignment .....	14
CB Receiver Alignment Procedure .....	14
Lock Out Circuit Check .....	15
Receiver Alignment .....	15
Tight Squelch Adjustment .....	15
Monitor Receiver Alignment Procedure .....	15
Receiver Alignment .....	15
<b>CHAPTER 4 - CHARTS AND DRAWINGS</b>	
Voltage Measurement Charts .....	21
Component Outline, Main P.C. Board .....	27
Component Outline, Monitor Receiver P.C. Board .....	31
Component Outline, LED P.C. Board .....	35
Component Outline, Switch P.C. Board .....	39
Parts List .....	43
Schematic .....	57

## LIST OF ILLUSTRATIONS

<b>Figure</b>		<b>page</b>
2-1	Block Diagram of PLL Circuitry .....	7
2-2	Block Diagram, CB Transceiver .....	foldout
2-3	Block Diagram, Monitor Receiver .....	foldout
3-1	Equipment Set-up, Transmitter Alignment .....	12
3-2	Connection of Frequency Counter and Dummy Load .....	13
3-3	Equipment Set-up, CB Receiver Alignment .....	14
3-4	Equipment Set-up, Monitor Receiver Alignment .....	15
3-5	Components Adjusted for Transmitter Alignment .....	17
3-6	Components Adjusted for CB Receiver Alignment .....	18
3-7	Components Adjusted for Monitor Receiver Alignment .....	19
4-1	Component Outline, Main P.C. Board .....	29
4-2	Component Outline, Monitor Receiver P.C. Board .....	33
4-3	Component Outline, LED P.C. Board .....	37
4-4	Component Outline, Switch P.C. Board .....	41
4-5	Schematic Diagram, Model 2706 .....	foldout



## CHAPTER 1 — GENERAL INFORMATION

### Introduction

This service manual contains all the information needed to service and repair the Hy-Gain 2706. It includes an explanation of the theory of operation and alignment procedures. Revision, addendum and errata sheets will be published as needed. Insert them as required in the manual.

### General Description

The Hy-Gain 2706 is a full 40 channel transceiver. It is transmitter type accepted and receiver certified for Class D Citizens Radio Service, as designated by the Federal Communications Commission (FCC).

The 2706 is a compact mobile unit, completely solid-state and highly reliable with low power consumption. The PLL (Phase Locked Loop) frequency synthesizer provides immediate operation on all 40 channels. Features include an Automatic Noise Limiter (ANL), an RF Gain control, and Public Address (PA) capabilities. The 2706 has an additional built-in receiver dedicated to a prespecified monitor channel, such as channel 9, to allow separate continuous monitoring. When the unit is set at the Monitor position, it will allow not only a selected channel to be received and transmitted on, but also allows a received monitor signal to over-ride the selected channel signal. It also has a Monitor Channel position, which provides two-way communications on the prespecified channel.

In addition, a Noise Blanker circuit, output jacks for an optional telephone style handset and an external speaker are included. Use the unit with 12 VDC (nominal), either negative or positive ground.

### Warranty Service Department

For help with technical problems, for parts information, and information on local and factory repair facilities, contact the National Service Manager. When you write, please include all pertinent information that may be helpful in solving the problem. Address the letter to:

Hy-Gain Warranty Service Department  
4900 Superior Street  
Lincoln, Nebraska 68504  
ATTN: National Service Manager

The Warranty Service Department can repair any unit. Before shipping the unit contact the National Service Manager. Often a problem is field solvable with a little extra help. This can save lost time and shipping costs. Limit factory returns to the difficult problems.

### How to Ship Returns

To return a unit, get a return authorization. This is important. Handling of the unit may be delayed if shipped without it. If the unit must be shipped immediately, telephone or telex the National Service Manager for expeditious service.

When you request authorization, notification of repairs may also be requested. The notification will include a copy of the bill. Paying the bill before the return of the unit can save the cost of a COD fee.

For warranty repair, prepare a letter in duplicate containing the following information (for out-of-warranty repair delete items 2 and 3):

1. your name and address
2. purchaser's name and address
3. proof of purchase
4. serial number
5. complete description of the problem
6. the return authorization

Check the unit to see that all parts and screws are in place and attach an envelope containing a copy of the letter directly to it so this information is not overlooked. Wrap the unit and the envelope in heavy paper or put it in a plastic bag. If the original carton is not available, place the unit in a strong carton at least six inches larger in all three dimensions than the unit. Fill the carton equally around the unit with resilient packing material (shredded paper, excelsior, bubble pack, etc.). Seal the box with gummed paper tape, tie it with strong cord, and ship it by prepaid express, United Parcel Service, or insured parcel post to the address given previously. Mail the original of the letter in a second envelope to that same address.

It is important that the shipment be well packed and fully insured. Damage claims can delay repair and return of the unit. All claims must be settled between you and the carrier.

All shipments must be sent PREPAID. We *do not* accept collect shipments. After the unit has been repaired we will send it back COD unless the bill has been prepaid. Unclaimed or refused COD shipments will not be reshipped until payment in full is received. These items become the property of Hy-Gain 60 days after refusal or return and will be sold for payment of charges due.

**Units with unauthorized field modifications cannot be accepted for repair.**

**Purchase of Parts**

Parts can be purchased from any Hy-Gain Service Center or from the factory Warranty Service Department. When ordering, please supply the following information:

1. unit model number
2. unit serial number
3. part description
4. part number

**Specifications**

*General*

Channels ..... all 40 channels in the citizens band (26.965 - 27.405 MHz)

Antenna impedance ..... 50 ohms nominal

Power requirements ..... 11.5 to 14.5 VDC negative or positive ground

Compliance ..... type accepted under the FCC rules and regulations, Part 95. Receiver certified under Part 15, FCC rules

*CB Receiver Section*

Circuitry ..... dual conversion superheterodyne with RF amplifier stage and 455 kHz ceramic filter

Sensitivity ..... 0.7 uV for 10 dB S/N ratio

Intermediate frequency ..... 1st IF - 10.695 MHz  
2nd IF - 455 kHz

Audio output ..... 3 watts

Current drain, receive ..... 200 mA (no signal)

*Monitor Receiver Section*

Circuitry ..... dual conversion superheterodyne  
with RF amplifier stage and 455 kHz  
ceramic filter  
Sensitivity ..... 1  $\mu$ V for 10 dB S/N ratio  
Intermediate frequency ..... 1st IF - 10.695 MHz  
2nd IF - 455 kHz

*Transmitter Section*

RF power output ..... 4 watts  
Emission ..... 6A3  
Spurious response rejection ..... all harmonic and spurious  
suppression better than FCC  
requirements  
Modulation ..... AM 90% typical  
Current drain, transmit ..... less than 1.1 amp at 13.8 VDC

## CHAPTER 2 — THEORY OF OPERATION

### General

The theory of operation of the Hy-Gain 2706 transceiver is divided into three sections: the Phase Locked Loop frequency synthesizer, the Receiver, and the Transmitter. This material covers the functioning of the transceiver with a minimum of technical involvement. We have not attempted to explain the engineering techniques and approaches that arrived at these circuit designs. Refer to the block diagram, figure 2-2, for visual reference to the theory of operation.

### Phase Locked Loop Frequency Synthesizer

Refer to the PLL Circuit block diagram, figure 2-1, for visual reference to the Phase Locked Loop frequency synthesizer.

The Phase Locked Loop (PLL) frequency synthesizer generates frequencies for use in both the transmitter and receiver sections. Its output determines the channel on which the transceiver is operating. The PLL circuitry incorporates two crystal oscillators to perform its frequency generating function.

The 10.24 MHz Oscillator, Q1, provides a reference for the PLL and an injection frequency for the Second Receiver Mixer, Q10.

The PLL circuit generates the operating frequencies needed for the transceiver in accordance with the code fed to the Programmable Divider, a portion of IC1, from the Channel Selector switch, SW-1a. Table A shows the following for each channel: the channel number, channel frequency, "N" digital code, VCO frequency, channel switch output, and the Receiver first local oscillator frequency.

For example, assume that channel 1 has been selected. The channel frequency is 26.965 MHz, the VCO frequency is 17.18 MHz, and the "N" code is 330. The Channel Selector switch programs the programmable divider for a division ratio of 330. The 10.24 MHz reference frequency is fed to the PLL IC, IC1. It is divided internally by 1024, producing a 10 kHz reference signal. The output of the VCO, D1, is mixed in the PLL Mixer portion of IC2 with the doubled output of the Reference Oscillator, Q1. The mixed and converted output difference frequency, 3.30 MHz, is then fed back to the PLL IC, IC1, through a buffer circuit in the VCO/Mixer IC, IC2, and a low pass filter circuit. In the PLL IC, IC1, the output difference frequency goes through a buffer circuit to the programmable divider, and is divided into a low frequency by the predetermined "N" code. The low frequency is fed to the phase detector and compared with the reference frequency.

The phase detector, which is internally located in the PLL IC, IC1, generates a DC output voltage corresponding to the phase difference between the two signals applied. The DC output is then applied to the VCO circuit, IC2, through a low pass filter. The VCO frequency will change so that the VCO frequency coincides with the reference frequency. The Phase Locked Loop circuitry will lock when the frequencies coincide with each other. When this happens, the VCO circuit provides stable frequencies over the band of 17.62 MHz (depending upon the "N" code or channel selected).

Assume that the channel is changed to channel 40. The Channel Selector switch now provides a code that will produce a division ratio of 286. At this instant the VCO frequency is at 17.18 MHz, which is mixed with the doubled output of the 10.24 MHz Reference Oscillator, Q1. Again the PLL Mixer produces an output of 3.30 MHz. The 3.30 MHz signal is divided by 286 to produce a frequency of 11.54 kHz. The 11.54 kHz output, along with the 10 kHz obtained from the Reference Oscillator, Q1, is fed to the phase detector. The comparison of the two frequencies in the phase detector produces an error output which is a combined AC-DC voltage. The low pass filter removes the AC component and allows

only the DC voltage to be fed to the VCO. The VCO frequency changes until the output of the programmable divider is again 10 kHz.

When this occurs the loop is considered locked and the VCO frequency is 17.62 MHz. With the Channel Selector at 40, the following outputs of the PLL circuitry are produced: the 17.62 MHz VCO output is mixed with the 20.48 MHz doubled output from the Reference Oscillator output to produce 38.10 MHz, which is fed to the First Receiver Mixer, Q9; and in the transmit mode, the 38.10 MHz is mixed with the 10.695 MHz output of the second oscillator portion of IC3 to produce a transmit frequency of 27.405 MHz.

### **CB Receiver**

The CB receiver is a dual-conversion superheterodyne, receiving AM signals from 26.965 MHz to 27.405 MHz. The operating channel is determined by the PLL frequency synthesizer, which provides the local oscillator frequency to the First Mixer. A variable squelch circuit is included to quiet the receiver between transmissions.

In the receive mode, 13.8 VDC is supplied to IC4, Q8, Q9, Q11, Q12 and Q6, the AVR. The AVR supplies regulated voltage to the synthesizer stages and to the Reference Oscillator, Q1. A bias voltage is also applied to the base of the Transmit switch, Q7, keeping it open so that the transceiver circuits remain in receive.

Radio signals are received by the antenna and enter the radio at the antenna jack. The filter formed by L11, L12, L13, C46, and C47 matches the antenna impedance to the RF Amplifier, Q8, and its tuned circuit, C51 and T5. D7 and D6 are a signal overload protective circuit.

The output of the RF Amplifier, Q8, and the buffered mixer in IC2, are applied to the First Receiver Mixer, Q9, and produce an output of 10.695 MHz, which is the IF. The first IF passes through tuned circuits, L14 and T7. It is then applied to the Second Receiver Mixer, Q10, which has a second input of 10.24 MHz from the Reference Oscillator, Q1. The output of Q10 is 455 kHz, which is the second IF.

The second IF passes through the Ceramic Filter, CF1, and is amplified by the First and Second IF Amplifiers, Q11 and Q12. The amplified signal is then fed to the Detector, D9. The Detector, D9, establishes an automatic gain control, AGC, voltage and recovers the audio from the modulated signal. The AGC voltage keeps the output volume of the receiver at a constant level under variations in input signal and also controls the Squelch Switch, Q13.

The squelch functions in the following manner: in the receive mode, a bias voltage from Q6 is applied to the base of Q13, as determined by VR2. In the absence of a signal the base of Q13 is positively biased and is on. This control signal is applied to the Squelch Logic Control, IC401, the Squelch Gate, Q408, and biases the squelch circuit inside the Audio Amplifier, IC4, which turns off the audio portion and quiets the receiver. When a signal is received, the voltage developed by D9 biases Q13 off. The control signal is processed by IC401 and Q408 again and biases the squelch circuit inside IC4 so that the audio portion is turned on and the signal is heard. The recovered audio from the Detector, D9, passes through a series Automatic Noise Limiter (ANL), D10. The output of the ANL goes through the Volume Control, VR1, and is coupled to the Audio Amplifier, IC4, through the Audio Logic Control, IC402. The amplified AF output from IC4 passes through the Audio Transformer, T11, to be applied to the speaker jacks and the speaker.

### **Monitor Receiver**

The Monitor Receiver is the same system as the CB Receiver with a prespecified receiving channel and associated control logic circuits. When the Mode Selector is placed in the MONITOR position 13.8 VDC is applied to the Monitor Receiver.




Figure 2-1. Block Diagram of PLL Circuitry

## N CODE — FREQUENCY CORRELATION CHART

**TABLE A**

Channel Number	Channel Frequency (MHz)	"N" Code	VCO Frequency (MHz)	A	B	C	D	A'	B'	C'	Receiver 1st Local Frequency (MHz)
1	26.965	330	17.18	0	1	0	1	0	0	1	37.66
2	26.975	329	17.19	1	0	0	1	0	0	1	37.67
3	26.985	328	17.20	0	0	0	1	0	0	1	37.68
4	27.005	326	17.22	0	1	1	0	0	0	1	37.70
5	27.015	325	17.23	1	0	1	0	0	0	1	37.71
6	27.025	324	17.24	0	0	1	0	0	0	1	37.72
7	27.035	323	17.25	1	1	0	0	0	0	1	37.73
8	27.055	321	17.27	1	0	0	0	0	0	1	37.75
9	27.065	320	17.28	0	0	0	0	0	0	1	37.76
10	27.075	319	17.29	1	1	1	1	1	1	0	37.77
11	27.085	318	17.30	0	1	1	1	1	1	0	37.78
12	27.105	316	17.32	0	0	1	1	1	1	0	37.81
14	27.125	314	17.34	0	1	0	1	1	1	0	37.82
15	27.135	313	17.35	1	0	0	1	1	1	0	37.83
16	27.155	311	17.37	1	1	1	0	1	1	0	37.85
17	27.165	310	17.38	0	1	1	0	1	1	0	37.86
18	27.175	309	17.39	1	0	1	0	1	1	0	37.87
19	28.185	308	17.40	0	0	1	0	1	1	0	37.88
20	27.205	306	17.42	0	1	0	0	1	1	0	37.90
21	27.215	305	17.43	1	0	0	0	1	1	0	37.91
22	27.225	304	17.44	0	0	0	0	1	1	0	37.92
23	27.255	301	17.47	1	0	1	1	0	1	0	37.95
24	27.235	303	17.45	1	1	1	1	0	1	0	37.93
25	27.245	302	17.46	0	1	1	1	0	1	0	37.94
26	27.265	300	17.48	0	0	1	1	0	1	0	37.96
27	27.275	299	17.49	1	1	0	1	0	1	0	37.97
28	27.285	298	17.50	0	1	0	1	0	1	0	37.98
29	27.295	297	17.51	1	0	0	1	0	1	0	37.99
30	27.305	296	17.52	0	0	0	1	0	1	0	38.00
31	27.315	295	17.53	1	1	1	0	0	1	0	38.01
32	27.325	294	17.54	0	1	1	0	0	1	0	38.02
33	27.335	293	17.55	1	0	1	0	0	1	0	38.03
34	27.345	292	17.56	0	0	1	0	0	1	0	38.04
35	27.355	291	17.57	1	1	0	0	0	1	0	38.05
36	27.365	290	17.58	0	1	0	0	0	1	0	38.06
37	27.375	289	17.59	1	0	0	0	0	1	0	38.07
38	27.385	288	17.60	0	0	0	0	0	1	0	38.08
30	27.395	287	17.61	1	1	1	1	1	0	0	38.09
40	27.405	286	17.62	0	1	1	1	1	0	0	38.10

When this occurs, both the CB Receiver and the Monitor Receiver are on. The CB Receiver will receive signals on any selected channel, and the Monitor Receiver will receive signals on the monitor channel. In addition, the signals received by the Monitor Receiver will over-ride the signals received by the CB Receiver when in the monitor position.

The entire Monitor Receiver functions exactly the same as the CB Receiver up to and including the ANL, D404. For example, a signal is received on channel 1 and another signal is received on the monitor channel at the same time. The CB signal is mixed, converted, amplified and detected in the usual manner and is applied to the Audio Logic Control, IC402a. At the same time, the monitor channel signal is received, mixed, converted, amplified and detected by the Monitor Receiver and is applied to the Audio Logic Control, IC402b. Squelch level on the monitor receiver is detected by Squelch Switch, Q407. When this occurs, an over-ride signal is sent to the Audio Logic Control,

IC402a, blocking the audio signal from the CB Receiver. The monitor signal is passed by the Audio Logic Control, IC402b, and is applied to the Audio Amplifier, IC4, and then to the speaker.

Whenever a signal is received on the monitor channel, there is a control signal applied to the Display Gate, Q409. The output of the Display Gate is applied to the Display Drivers, Q410 and Q411. The output of the Display Drivers will turn off the LED display. In addition, the output of the Display Gate, Q409, goes to the Light Driver, Q1, on the light control board, which turns on the Monitor Indicator Light. A transmit-receive bias from Q7 is applied to IC401, the Display Logic Control, which turns on the LED display and turns off the monitor indicator when the PTT switch is closed.

### **Monitor Channel**

When the Mode switch is turned to the Monitor Channel position, 13.8 VDC is applied to the Display Control Diode, D406, turning on the Monitor Channel Indicator. 5 VDC is applied to the monitor diode matrix which drives the PLL circuitry on the main p.c. board, and the entire transceiver is programmed for two-way communications over the monitor channel.

### **Transmitter**

Switching to the transmit mode is accomplished in the following manner: when the PTT switch is closed, the base of the DC Switch, Q7, is grounded. This establishes forward bias which causes Q7 to conduct. Regulated voltage from the Automatic Voltage Regulator, Q6, is then supplied through Q7 to the Transmit Oscillator Mixer, IC3. When the PLL IC, IC1, is locked, and IC3 operates in the transmit mode, a control voltage actuates the DC Switch, Q22, and allows RF drive to the RF Pre-Driver, Q3, the RF Driver, Q4, and the RF Power Amplifier, Q5.

The operating channel is determined by the PLL frequency synthesizer, IC1. The VCO frequency is mixed in IC2 with the 20.48 MHz signal to yield a 37.66 to 38.10 MHz signal which is applied to IC3.

In IC3 the signal is mixed with a 10.695 MHz signal from the crystal, X2, and an internal oscillator to provide the 26.965 to 27.405 MHz transmit frequency. The transmit frequency from IC3 passes through the filter circuit of L5 and T3 and is applied to the RF Pre-Driver, Q3. The filter circuit partially removes spurious signals from the transmit frequency.

The Pre-Driver, Q3, and the RF Driver, Q4, form two stages of amplification leading to the final stage. The filter circuit of T4 follows Q3, and L7 follows Q4. These two circuits filter out the remaining spurious signals from the transmit frequency.

From the RF Driver, Q4, the signal is applied to the final stage, the RF Power Amplifier, Q5. This is a current amplifier that raises the transmit signal to an output of four watts. Its output is applied to a filter, consisting of L11, C46, C47, L12, C14 and L13, and then to the antenna jack.

The transmit signal is modulated in the following manner: the microphone output is applied to the Audio Amplifier, IC4. The output of IC4 is applied to the collectors of the RF Driver, Q4, and the RF Power Amplifier, Q5, through the Audio Output Transformer, T11. Control voltages for the Automatic Level Compensation circuit (ALC), composed of Q15 and Q14, come from the Detector Diodes, D11 and D12. The transmit audio ALC boosts, or lowers, the amplifier gain in response to line voltage fluctuations. This insures full modulation of the carrier despite any changes in line voltage. Q14 reduces AF peaks so that a higher average AF level is supplied to the Audio Amplifier. This gives the desired high average modulation without overmodulation of peaks.



**Noise  
Blanking  
Circuit**

This circuit silences undesirable impulse noises by disabling the receiver circuit for the short time the impulse is applied to the antenna circuit.

When the ANL-NB switch, S2, is in the NB position, noise impulses will be picked up through capacitor C134 and applied to the base of the Noise Amplifier, Q18. Q18 will amplify the impulse which is then applied to Voltage Detectors, D18 and D19. D18 and D19 rectify the amplified impulses, and the resultant DC voltage is applied to the Noise Blanker Switch, Q19. Q19 then turns on the Noise Blanker, Q20. When Q20 operates, it causes T8 to short circuit to ground, thereby inactivating the receiver circuit for a short time. The noise impulse duration determines the cut-off time the receiver will be silenced during reception of noise impulses. Similar noise blanking function is performed by Q404 on the Monitor Receiver.

**Transmitter  
Lamp Circuit**

When the Switching Transistor, Q7, supplies DC voltage to the transmit circuit, the voltage is also applied to terminal 3 on EPO-0649. This makes Q2 (on EPO-0649) activate. The Transmitter Lamp, PL2 will be lit indicating a transmit condition.

**PA Amplifier  
and Switch**

When the PA mode is selected by placing S3 in the PA position, the PA Gate Switch, Q4, is grounded. With Q4 grounded all other functions of the unit except the PA are inoperative.

The PA Audio Gate, Q3, functions as an amplifier for the microphone when it is not clamped to AC ground by Q4. The audio signal from the microphone is amplified by Q3 and is then applied to the Audio Amplifier, IC4. The audio signal is amplified by IC4 and is then applied to the PA jack, J4.

## CHAPTER 3 — ALIGNMENT

### General

These procedures must be followed to align the 2706 transceiver. Alignment should not be undertaken unless the technician has adequate test equipment and a full understanding of the circuitry of the transceiver.

**IMPORTANT:** Tuning adjustment of these transceivers "shall be made by or under the immediate supervision and responsibility of a person holding a first or second class commercial radio operator's license", as stipulated in Part 95.97 (b) of the FCC Rules and Regulations.

The procedures are divided into two main sections: Transmitter Alignment and Receiver Alignment. See *Equipment* below for a complete list of recommended equipment

These procedures assume that proper voltages are present at all points in the unit, if not, troubleshoot before continuing.

**NOTE:** The ferrite cores in the tuned coils are easily chipped or broken. Always use care when inserting an alignment tool in the coil: insert it straight into the core.

### Recommended Tools and Equipment

The following equipment is recommended for use in aligning the Hy-Gain 2706 transceiver:

- Audio Signal Generator, 1 kHz
- AC VTVM, 1 mV measurable
- DC Ampere Meter, 2A
- Variable Regulated Power Supply, DC 8-15V, 2A
- Frequency Counter, 0 to 40 MHz, high input impedance type
- VTVM with RF probe
- Oscilloscope, 30 MHz, high input impedance
- Low capacitance RF probe, capacitance not to exceed 13 pF
- RF Wattmeter and 50 ohm, 5 watt dummy load
- Standard RF Signal Generator, 27 MHz CB band
- Speaker dummy resistor, 8 ohm, 5 watt
- VOM, 20 kohm/V

All test equipment should be properly calibrated.

**NOTE:** Test voltage is 13.8 VDC unless otherwise specified.

### Transmitter Alignment Procedure


#### **Equipment Set-up**

Refer to figure 3-1 for the test equipment set-up.

Refer to figure 3-5 for location of components to be adjusted for transmitter alignment.

Connect test equipment as shown below.

EO-2679-B-111



**Figure 3-1. Equipment Set-up, Transmitter Alignment**

**Pre-Alignment Frequency Check**

Before alignment, use the frequency counter through a 1000 pF coupling capacitor connected in series with the counter input probe to check the operating frequencies at the following points.

Emitter of Q2, reference input, check to read 10.24 MHz accurate to four significant digits.

Pin 6 of IC2, transceiver on channel 1, check to read 37.66 MHz accurate to four significant digits.

**VCO Circuit Alignment**

1. Place the Channel Selector in channel 1 position.
2. Connect the VOM (DC 12V range) between ground and TP8.
3. Adjust L1 core to obtain a reading no lower than  $3.6V \pm .1V$ .
4. Place the Channel Selector in channel 40 position. The reading should be within  $1.5V \pm .1V$ .

**RF Driver Stage Alignment**

**NOTE:** An RF VTVM is the preferred test equipment for this alignment. In part 3, T1 *must* be adjusted with an RF VTVM to prevent detuning of the circuit. If an oscilloscope is used for the rest of the alignment procedures, use a low capacity (less than 1 uF) high impedance probe.

1. Place the Channel Selector in channel 19 position.

2. Connect the RF VTVM to the base of Q3 and ground.
3. Adjust T1, L2, T2, L5 and T3 in that order for maximum amplitude on the RF VTVM.
4. Reduce the power supply voltage from 13.8 to 7.0V, and connect the RF VTVM between the base of Q4 and ground.
5. Adjust T3 and T4 for maximum amplitude on the RF VTVM.


### **RF Power Amplifier Alignment**

1. Set the power supply voltage to 13.8V. Place the Channel Selector switch in the channel 19 position.
2. Connect the RF wattmeter to the Antenna Connector of the transceiver.
3. Adjust L7 for maximum reading on the RF wattmeter.
4. Adjust L11 for maximum reading on the RF wattmeter.
5. Adjust L12 for maximum reading on the RF wattmeter.
6. Readjust L11 for maximum reading.
7. Turn the core of L7 clockwise so that the RF wattmeter indicates 4.4 watts.
8. Turn the core of L12 counterclockwise until the power reading is 3.8 watts.

### **Transmitter Frequency Check**

1. Turn the transceiver off.
2. Connect the dummy load and frequency counter to the antenna jack as shown in figure 3-3.
3. Turn the transceiver on.

EO-0672-A-010



**Figure 3-2. Connection of Frequency Counter and Dummy Load**

4. Key the transmitter with the microphone PTT button.
5. Check the frequency of each channel with the following chart. Frequencies should be within 800Hz at 25° centigrade.

#### CHANNEL FREQUENCY


Channel	MHz	Channel	MHz
1	26.965	21	27.215
2	26.975	22	27.225
3	26.985	23	27.255
4	27.005	24	27.235
5	27.015	25	27.245
6	27.025	26	27.265
7	27.035	27	27.275
8	27.055	28	27.285
9	27.065	29	27.295
10	27.075	30	27.305
11	27.085	31	27.315
12	27.105	32	27.325
13	27.115	33	27.335
14	27.125	34	27.345
15	27.135	35	27.355
16	27.155	36	27.365
17	27.165	37	27.375
18	27.175	38	27.385
19	27.185	39	27.395
20	27.205	40	27.405

#### **Modulation Sensitivity Alignment**

1. Place the unit in the transmit mode and apply a 20 mV, 1 kHz signal to the junction of C80, R58 and C81 on the radio PC board.
2. Adjust RV2 to obtain 90% modulation as observed on the oscilloscope.
3. Decrease the signal input to 6 mV. Modulation should not fall below 80%.

#### **CB Receiver Alignment Procedure**

Refer to figure 3-6 for the location of components to be adjusted for receiver alignment.



**Figure 3-3. Equipment Set-up, CB Receiver Alignment**

### **Lock Out Circuit Check**

Position the Channel Selector switch in the open channel position. Check the voltage at the base of Q3. The voltage should be between 0.05 to 0.4V.

### **Receiver Alignment**

Place the ANL switch in the "OFF" position. To put the transceiver into the receive mode, short pins 5 and 3 of the MIC jack on the front panel together.

1. Set the signal generator to 27.185, 1 kHz, 30% modulation and set the transceiver to channel 19. Set the CB squelch fully counter clockwise.

**NOTE:** This alignment should be performed with an extremely small signal input from the signal generator to avoid inaccurate alignment due to AGC action.


2. Adjust T5, T6, L14, T7, T8, T9 and T10 for maximum audio output as indicated on the AC VTVM (or oscilloscope if used).
3. Turn the core of T5 one turn clockwise.

### **Tight Squelch Adjustment**

1. Set the signal generator to provide an RF input signal of 100 uV, 1 kHz, 30% modulation.
2. Rotate the CB squelch control fully clockwise.
3. Adjust RV1 so that the squelch just breaks with the 100 uV signal input.

### **Monitor Receiver Alignment Procedure**

Refer to figure 3-7 for the location of components to be adjusted for receiver alignment.



**Figure 3-4. Equipment Set-up, Monitor Receiver Alignment**

### **Receiver Alignment**

Place the ANL switch in the "OFF" position.

To put the transceiver into the receive mode, short pins 5 and 3 of the MIC jack on the front panel together.


1. Set the signal generator to 27.065 MHz, 1 kHz, 30% modulation and set the Mode Select switch to "MON" position. Set the Monitor Squelch fully counter clockwise.

**NOTE:** This alignment should be performed with an extremely small signal input from the signal generator to avoid inaccurate alignment due to AGC action.

2. Adjust T405, T406, L414, T407, T408, T409 and T410 for maximum audio output as indicated on the AC VTVM (or oscilloscope if used).
3. Turn the core of T401 one turn counter clockwise.

### ***Tight Squelch Adjustment***


1. Set the signal generator to provide an RF input signal of 70 uV, 1 kHz, 30% modulation.
2. Rotate the monitor squelch control fully clockwise.
3. Adjust RV400 so that the squelch just breaks with the 70 uV signal input.



(FRONT PANEL)

Figure 3-5. Components Adjusted for Transmitter Alignment





(FRONT PANEL)

Figure 3-6. Components Adjusted for CB Receiver Alignment




Figure 3-7. Components Adjusted for Monitor Receiver Alignment

## CHAPTER 4 — CHARTS AND DRAWINGS



Voltage Charts

### VOLTAGE MEASUREMENT CHART

Reference Designator	Mode	E	B	C
Q1	RX	2.8V	3.3V	5.6V
	TX	2.8V	3.3V	5.6V
Q2	RX	2.8V	2.9V	5.6V
	TX	2.8V	2.9V	5.6V
Q3	RX	1.8V	2.6V	13.8V
	TX	1V	1/7V	13.8V
Q4	RX	0	0	13.8V
	TX	0	0	10.5V
Q5	RX	0	0	13.8V
	TX	0	0	10.5V
Q6	RX	8.8V	9.4V	13.8V
	TX	8.8V	9.4V	12.5V
Q7	RX	8.8V	8.3V	0
	TX	8.8V	8V	8.7V
Q8	RX	1.5V	2.2V	13V
	TX	1.95V	.25V	13V
Q9	RX	1.6V	2.15V	11.5V
	TX	0	.25V	13V
Q10	RX	0	.6V	0
	TX	0	0	0
Q11	RX	1.5V	1.75V	12.2V
	TX	0	.25V	13V
Q12	RX	.85V	1.5V	12.8V
	TX	0	.15V	13V
Q13	RX	0	0	13V
	TX	0	.65V	0
Q14	RX	1.5V	7.1V	0
	TX	1.5V	6.8V	0
Q15	RX	0	0	0
	TX	0	0	0
Q18	RX	0	.7V	4V
	TX	0	.7V	4V
Q19	RX	0	0	0
	TX	0	0	0
Q20	RX	0	0	0
	TX	0	0	0
Q22	RX	4.5V	.9V	5.6V
	TX	4.2V	.9V	5.6V
with Noise Blanker on				
Q18	RX	0	.7V	4V
Q19	RX	8.8V	8.2V	0
Q20	RX	0	0	0

Reference Designator	Mode	E	B	C
Q401	RX	1.95V	2.42V	11.7V
	TX	3.5V	.6V	13.5V
Q402	RX	1.9V	2.4V	10.8V
	TX	.1V	.5V	13.5V
Q403	RX	0	.35V	0
	TX	0	0	0
Q404	RX	0	0	0
	TX	0	0	0
Q405	RX	1.85V	2.09V	11.2V
	TX	0	.27V	13.4V
Q406	RX	.75V	1.5V	12.9V
	TX	0	.15V	13.5V
Q407 unsquelched	RX	0	0	11.8V
	TX	0	0	12V
Q407 squelched	RX	0	.62V	0
	TX	0	.15V	12V
Q408	RX	0	0	6.5V
	TX	0	0	6.5V
Q409	RX	11.8V	12V	13.5V
display off	TX	0	0	13.5V
Q409	RX	0	0	13.5V
display on	TX	0	0	13.5V
Q410	RX	3.6V	2.2V	0
display on	TX	3.2V	1.2V	0
Q410	RX	11.2V	11V	0
display off	TX	3.2V	1.2V	0
Q411	RX	12.8V	11V	0
display off	TX	3.9V	3.2V	0
Q411	RX	4.2V	3.6V	0
display on	TX	3.9V	3.2V	0
Q412	RX	1V	1.5V	11V
	TX	0	.15V	13.5V

**IC 401**

Pin No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14
Unsquelched	13.5V	.9V	0	0	2.4V	8.5V	0	8.5V	8.5V	0	13.5V	0	.9V	13.5V
Squelched	13.5V	.9V	0	13.5V	0	0	0	0	0	13.5V	0	13.5V	.9V	13.5V

**IC 402**

PIN No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14
Unsquelched	.07V	.07V	.07V	.05V	0	13.5V	0	13.5V	13.5V	13.5V	0	0	11V	0
Squelched	0	0	0	0	13.5V	13.5V	0	13.5V	13.5V	13.5V	13.5V	13.5V	0	13.5V

**IC 2 VCO/MIXER**

Pin No.	1	2	3	4	5	6	7	8	9
Measured in receive	2.5V	2V	1.3V	2.35V	0	8.5V	2.1V	4.4V	1.6V

**IC 3 OSC 2/MIXER**

Pin No.	1	2	3	4	5	6	7	8	9
Measured in transmit	3.6V	2.1V	1.4V	2.7V	0	8.6V	2.1V	7.8V	8.2V

**IC 4 (BA52)**

Pin No.	1	2	3	4	5	6	7	8	9	10
Squelched	12.69V	0	0	6.76V	5.8V	2.9V	.10V	13.61V	13.64V	13.71V
Unsquelched	6.82V		1.28V	6.76V	6V	6.70V	.98V	8.06V	13.39V	13.70V

**IC 1 (PLL 02A)**

Pin No.	Voltage	Channels Selected
1	5.6V	N/A
2	.2V	N/A
3	.8V	N/A
4	5.4V	N/A
5	2 - 3.6V	40 - 1
6	5.6V	N/A
7	5.6V	N/A
8	0	N/A
9	5.6V	1, 2, 3, 4, 5, 6, 7, 8, 9
10	5.6V	10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38
11	5.6V	10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 39, 40
12	5.6V	1, 2, 3, 10, 11, 12, 13, 14, 15, 23, 24, 25, 26, 27, 28, 29, 30, 39, 40
13	5.6V	4, 5, 6, 10, 11, 12, 16, 17, 18, 19, 23, 24, 25, 26, 31, 32, 33, 34, 39, 40
14	5.6V	1, 4, 7, 10, 11, 13, 14, 16, 17, 20, 24, 25, 27, 28, 31, 32, 35, 36, 39, 40
15	5.6V	2, 5, 7, 8, 10, 13, 15, 16, 18, 21, 23, 24, 27, 29, 31, 33, 35, 37, 39
16	0	N/A

**Front Panel Lamp Controller  
Q1 - Q4 (2SC945)**

Reference Designator	Mode	E	B	C				
Q1	RX	0	.7V	0				
	TX	0	.7V	12.8V				
Q2	RX	0	0	12.8V				
	TX	0	.7V	0				
Q3	RX	0	0	0	PA	.1V	.6V	.1V
	TX	0	0	0				
Q4	RX	0	.6V	0	PA	0	.1V	.6V
	TX	0	.6V	0				

**NOTE:** All voltage measurements are taken with the external power supply set at exactly 13.8 VDC.

**Component Outline**  
**Main P.C. Board**









Figure 4-1. Component Outline, Main P.C. Board


**Component Outline  
Monitor Receiver P.C. Board**






**Figure 4-2. Component Outline, Monitor Receiver P.C. Board**

**Component Outline**  
**LED P.C. Board**



TO CHANNEL SELECTOR P.C. BOARD




**NOTES:**

P.C. board shown as viewed from the component side.

**Figure 4-3. Component Outline, LED P.C. Board**



**Component Outline  
Switch P.C. Board**



**NOTES:**

P.C. board shown as viewed from component side.

**Figure 4-4. Component Outline, Switch P.C. Board**

**Parts List**



## Main P.C. Board

Reference Designator	Description	Part No.
	main p.c. board, complete .....	AP-TBM051FT
	main p.c. board, plated and drilled .....	PT-BM051AOX
C1	.1uF, 10V, arox .....	CD-A1AOR1ME
C2	10uF, 16V, electrolytic .....	CE-ED100ZMN
C3	.22uF, 10V, arox .....	CD-A1AR22ME
C4	68pF, 50V, ceramic .....	CC-CB680KPM
C5	.01uF, 50V, ceramic .....	CK-CB103PEM
C6	22pF, 50V, ceramic .....	CC-CB220KPM
C7	330pF, 50V, ceramic .....	CC-CB331KOM
C8	150pF, 50V, ceramic .....	CK-CB151KOM
C9	.047uF, 50V, ceramic .....	CK-CB473ZFM
C10	47pF, 50V, ceramic .....	CC-CB470KOM
C11	47uF, 10V, electrolytic .....	CE-EC470ALN
C12	18pF, 50V, ceramic .....	CC-CB180KPM
C13	1000pF, 50V, mylar .....	CQ-MB102KCH
C14	68pF, 50V, ceramic .....	CC-CB680KOM
C15	.01uF, 50V, ceramic .....	CK-CB103PEM
C16	33pF, 50V, ceramic .....	CC-CB320KPM
C17	47pF, 50V, ceramic .....	CC-CB470KPM
C18	1uF, 50V, electrolytic .....	CE-EG010ALN
C19	1000pF, 50V, mylar .....	CQ-MB102KCH
C20	1000pF, 50V, mylar .....	CQ-MB102KCH
C21	1000pF, 100V, styroflex .....	CQ-SC102KEF
C22	2pF, 50V, ceramic .....	CC-CB020COM
C23	7pF, 50V, ceramic .....	CC-CB070DOM
C24	33pF, 50V, ceramic .....	CC-CB330KPM
C25	4pF, 50V, ceramic .....	CC-CB040CPM
C26	330pF, 100V, styroflex .....	CQ-SC331KEF
C27	390pF, 50V, ceramic .....	CK-CB391KBM
C28	.01uF, 50V, ceramic .....	CK-CB103PEM
C29	68pF, 50V, ceramic .....	CC-CB680KOM
C30	56pF, 50V, ceramic .....	CC-CB560KOM
C31	.01uF, 50V, ceramic .....	CK-CB103PEM
C32	2pF, 50V, ceramic .....	CC-CB020COM
C33	.01uF, 50V, ceramic .....	CK-CB103PEM
C34	not used	
C35	68pF, 50V, ceramic .....	CC-CB680KOM
C36	.01uF, 50V, ceramic .....	CK-CB103PEM
C37	100pF, 50V, ceramic .....	CC-CB101KPM
C38	.01uF, 50V, ceramic .....	CK-CB103PEM
C39	.01uF, 50V, mylar .....	CQ-MB103KCH
C40	330pF, 50V, ceramic .....	CK-CB331KBM
C41	.01uF, 50V, ceramic .....	CK-CB103PEM
C42	120pF, 50V, ceramic .....	CC-CB121KOM
C43	220pF, 50V, ceramic .....	CC-CB221KOM
C44	120pF, 50V, ceramic .....	CC-CB121KOM
C45	.01uF, 50V, ceramic .....	CK-CB103PEM
C46	120pF, 50V, ceramic .....	CC-CB121KOM
C47	270pF, 500V, mica .....	CM-SD2/1KCS
C48	2pF, 500V, ceramic .....	CC-CE020COM
C49	.0047uF, 50V, ceramic .....	CK-CB472PEM

Reference Designator	Description	Part No.
C50	1uF, 50V, electrolytic	CE-EG010ALN
C51	27pF, 50V, ceramic	CC-CB270KOM
C52	.01uF, 50V, ceramic	CK-CB103PEM
C53	.047uF, 50V, ceramic	CK-CB473ZFM
C54	.047uF, 50V, mylar	CQ-MB473KCH
C55	.047uF, 50V, ceramic	CK-CB473ZFM
C56	.01uF, 50V, ceramic	CK-CB103PEM
C57	10pF, 50V, ceramic	CC-CB100DOM
C58	.01uF, 50V, ceramic	CK-CB103PEM
C59	.01uF, 50V, ceramic	CK-CB103PEM
C60	.01uF, 50V, ceramic	CK-CB103PEM
C61	.01uF, 50V, ceramic	CK-CB103PEM
C62	.01uF, 50V, ceramic	CK-CB103PEM
C63	1pF, 50V, ceramic	CC-CB020COM
C64	.01uF, 50V, ceramic	CK-CB103PEM
C65	18pF, 50V, ceramic	CC-CB180KPM
C66	2.2pF, 500V, minic	CG-2H2R2KNN
C67	.047uF, 50V, mylar	CQ-MB473KCH
C68	.047uF, 50V, mylar	CQ-MB473KCH
C69	.047uF, 50V, mylar	CQ-MB473KCH
C70	.047uF, 50V, mylar	CQ-MB473KCH
C71	.047uF, 50V, mylar	CQ-MB473KCH
C72	10uF, 16V, electrolytic	CE-ED100ALN
C73	6800pF, 50V, mylar	CQ-MB682KCH
C74	3.3uF, 25V, electrolytic	CE-EE3R3ALN
C75	4700pF, 50V, mylar	CQ-MB472KCH
C76	1uF, 50V, electrolytic	CE-EG010ALN
C77	.0015uF, 50V, mylar	72A376
C78	47uF, 16V, electrolytic	CE-ED470ALN
C79	.022uF, 50V, mylar	CQ-MB223KCH
C80	2200pF, 50V, ceramic	CC-CB222KBM
C81	.022uF, 50V, mylar	CQ-MB223KCH
C82	220pF, 50V, ceramic	CC-CB221KOM
C83	.01uF, 50V, mylar	CQ-MB203KCH
C84	390pF, 50V, ceramic	CK-CB391KBM
C85	5.6uF, 25V, tantalum	CS-SE5R6MDN
C86	.47uF, 10V, arox	CD-A1AR47ME
C87	33uF, 6.3V, electrolytic	CE-EB330ALN
C88	68pF, 50V, ceramic	CC-CB680KOM
C89	68pF, 50V, ceramic	CC-CB680KOM
C90	470pF, 50V, ceramic	CK-CB471KBM
C91	.068uF, 50V, mylar	CQ-MB683KCH
C92	.022uF, 50V, ceramic	CK-CB223ZFM
C93	47uF, 16V, electrolytic	CE-ED470ALN
C94	220uF, 16V, electrolytic	CE-AD221ZLS
C95	.068uF, 50V, mylar	CQ-MB683KCH
C96	3.3uF, 25V, electrolytic	CE-EE3R3ALN
C97	47uF, 10V, electrolytic	CE-EC470ALN
C98	not used	
C99	47uF, 25V, electrolytic	CE-AE470ZLS
C100	1000uF, 16V, electrolytic	CE-ED102ZUN
C101	33uF, 6.3V, electrolytic	CE-EB330ALN
C102	.01uF, 50V, ceramic	CK-CB103PEM

Reference Designator	Description	Part No.
C103 thru		
C105	not used	
C106	.047uF, 50V, ceramic	CK-CB473ZFM
C107	.047uF, 50V, ceramic	CK-CB473ZFM
C108 thru		
C109	not used	
C110	18pF, 50V, ceramic	CC-CB180KOM
C111	82pF, 50V, ceramic	CC-CB820KOM
C112	39pF, 50V, ceramic	CC-CB390KOM
C113	.01uF, 50V, ceramic	CK-CB103PEM
C114	390pF, 500V, ceramic	CC-CE391KOM
C115	18pF, 50V, ceramic	CC-CB180KOM
C116	not used	
C117	4700pF, 50V, ceramic	CK-CB472KBM
C118	.022uF, 50V, ceramic	CK-CB223ZFM
C119	not used	
C120	33uF, 16V, electrolytic	CE-ED330ALN
C121 thru		
C133	not used	
C134	3pF, 50V, ceramic	CC-CB030DOM
C135	220pF, 50V, ceramic	CC-CB221KOM
C136	.0033uF, 100V, styroflex	CQ-SC332KEF
C137	.01uF, 50V, ceramic	CK-CB103PEM
C138	220pF, 50V, ceramic	CC-CB221KOM
CF1	4 element ceramic filter	FB-R455A08M
CH1	choke coil	LJ-119H001Y
CT1	20pf, trimmer capacitor	CT-Z7200H01
D1	ITT410, silicon	QD-CTT410XQ
D2	MZ205, zener	QD-ZM205XE
D3	RD9.1E, zener	QD-ZRD9EXAA
D4	1S1555, silicon	QD-SS1555XT
D5	1N60, germanium	QD-G1N60XXT
D6	1S1555, silicon	QD-SS1555XT
D7	1S1555, silicon	QD-SS1555XT
D8	1N60, germanium	QD-G1N60XXT
D9	1N60, germanium	QD-G1N60XXT
D10	1S1555, silicon	QD-SS1555XT
D11	1S1555, silicon	QD-SS1555XT
D12	1S1555, silicon	QD-SS1555XT
D13	V06C, silicon	QD-SV06CXXB
D14	1S1885, silicon	QD-SS1885XT
D15	1S1555, silicon	QD-SS1555XT
D16	1S1555, silicon	QD-SS1555XT
D17	1S1555, silicon	QD-SS1555XT
D18	1N60, germanium	QD-G1N60XXT
D19	1N60, germanium	QD-G1N60XXT
D20 thru		
D21	not used	
D22	1S1555, silicon	QD-SS1555XT
D23	1N4148, silicon	76A037

Reference Designator	Description	Part No.
D24	1N4148, silicon	76A037
D25	1N4148, silicon	76A037
D26	1N4148, silicon	76A037
D27	1N4148, silicon	76A037
D28	1N4148, silicon	76A037
D28	1N4148, silicon	76A037
D29	1N4148, silicon	76A037
IC1	PLL02A	QQ-OPLL02A0
IC2	TA7310P	QQ-MC3001AT
IC3	TA7310P	QQ-MC3001AT
IC4	BA521A	QQ-MB521AX
L1	rf coil, 18 MHz	TR-10DD003S
L2	rf coil, 37 MHz	TR-10MB003T
L3	rf coil, 68uH, peaking	LF-680KD01N
L4	rf coil, 1 uH	LF-1R0KD01N
L5	rf coil, 27 MHz	TR-10CB002M
L6	rf coil, 2.2uH, peaking	LF-2R2KD01N
L7	rf coil, 27 MHz	TR-A5CZ001M
L8	rf coil, 68uH, peaking	LF-680KD01N
L9	rf coil, .55uH	LA-1KE1011A
L10	rf coil, 1.0uH	LD-ADX3825M
L11	rf coil, 27 MHz	TR-A5CZ002M
L12	rf coil, 27 MHz	TR-A5CZ003M
L13	rf coil, .40uH	LA-1JG1010A
L14	rf coil, 10.7 MHz	TR-07MB008N
L15	rf coil, 68uH, peaking	LF-680DK01N
L16	rf coil, .75uH	LD-ADB4024B
L17	rf coil, .75uH	LD-ADB4024B
Q1	2SC710DE	QT-C0710XEE
Q2	2SC710DE	QT-C0710XEE
Q3	2SC1687	QT-C1687XAN
Q4	2SC1846QRS	QT-C1846XAN
Q5	2SC1306	QT-C1306XZA
Q6	2SC1318QR	QT-C1318XDN
Q7	2SA719PQR	QT-A0719XHN
Q8	2SC1047BC	QT-C1047XBN
Q9	2SC1359BC	QT-C1359XBN
Q10	2SC710D	QT-C0710XBE
Q11	2SC710D	QT-C0710XBE
Q12	2SC829BC	QT-C0829XEN
Q13	2SC828P	QT-C0828XAN
Q14	2SA7190	QT-A0719XAN
Q15	2SC945(L)PQ	QT-C0945LAA
Q16 thru		
Q17	not used	
Q18	2SC829C	QT-C0829XBN
Q19	2SA733PQ	QT-A0733XDA
Q20	2S1327TU	QT-C1327XAN
Q21	not used	
Q22	2SC900UE	QT-C0900XEA

Reference Designator	Description	Part No.
<b>NOTE:</b> all resistors 5%, ¼ watt, carbon film unless otherwise noted.		
R1	3.3k	RD-25RJ332N
R2	470	RD-25RJ471N
R3	22k	RD-25RJ223N
R4	47k	RD-25RJ473N
R5	68	RD-25RJ680N
R6	680	RD-25RJ681N
R7	27k	RD-25RJ273N
R8	15k	RD-25RJ153N
R9	1.5k	RD-25RJ152N
R10	not used	
R11	82	RD-25RJ820N
R12	2.2k	RD-25RJ222N
R13	150	RD-25RJ151N
R14	1M	RD-25RJ105N
R15	47	RD-25RJ470N
R16	100	RD-25RJ101N
R17	5.6k	RD-25RJ562N
R18	68	RD-25RJ680N
R19	100	RD-25RJ101N
R20	220	RD-25RJ221N
R21	10, 5%, ½w, metal oxide film	RX-HAPJ100B
R22	68	RD-25RJ680N
R23	47k	RD-25RJ473N
R24	680	RD-25RJ681N
R25	330	RD-25RJ331N
R26	1k	RD-25RJ102N
R27	680	RD-25RJ681N
R28	47k	RD-25RJ473N
R29	3.3k	RD-25RJ332N
R30	100	RD-25RJ101N
R31	1.8k	RD-25RJ182N
R32	560	RD-25RJ561N
R33	470	RD-25RJ471N
R34	470k	RD-25RJ474N
R35	1k	RD-25RJ102N
R36	4.7k	RD-25RJ472N
R37	470	RD-25RJ471N
R38	47k	RD-25RJ473N
R39	220	RD-25RJ221N
R40	3.9k	RD-25RJ392N
R41	15k	RD-25RJ153N
R42	33k	RD-25RJ333N
R43	220	RD-25RJ221N
R44	47	RD-25RJ470N
R45	22k	RD-25RJ223N
R46	270k	RD-25RJ274N
R47	47k	RD-25RJ473N
R48	68k	RD-25RJ683N
R49	33k	RD-25RJ333N
R50	47k	RD-25RJ473N
R51	10k	RD-25RJ103N
R52	10, ½ watt, metal oxide film	RX-HAPJ100B

<b>Reference Designator</b>	<b>Description</b>	<b>Part No.</b>
R53	1k .....	RD-25RJ102N
R54	220 .....	RD-25RJ221N
R55	10k .....	RD-25RJ103N
R56	820 .....	RD-25RF821N
R57	27k .....	RD-25RJ273N
R58	3.3k .....	RD-25RJ332N
R59	3.3k .....	RD-25RJ332N
R60	2.2k .....	RD-25RJ222N
R61	not used	
R62	10 .....	RD-25RJ100N
R63	10k .....	RD-25RJ103N
R64	47 .....	RD-25RJ470N
R65	1k .....	RD-25RJ102N
R66	4.7k .....	RD-25RJ472N
R67	18k .....	RD-25RJ183N
R68	1k .....	RD-25RJ102N
R69	22k .....	RD-25RJ223N
R70	22k .....	RD-25RJ223N
R71	1.8k .....	RD-25RJ182N
R72	not used	
R73	4.7k .....	RD-25RJ472N
R74	100 .....	RD-25RJ101N
R75	4.7k .....	RD-25RJ472N
R76	not used	
R77	270, ½ watt, metal oxide film .....	RG-HANJ271B
R78	15, 2 watt, metal oxide film .....	RX-2ANJ150B
R79	1k .....	RD-25RJ102N
R80	6.8k, solid .....	RC-14GK682N
R81	1.5k .....	RD-25RJ152N
R82	4.7k .....	RD-25RJ472N
R83 thru		
R89	not used	
R90	100k .....	RD-25RJ104N
R91	1k .....	RD-25RJ102N
R92	560k .....	RD-25RJ561N
R93	100k .....	RD-25RJ104N
R94	820k .....	RD-25RJ824N
R95	4.7k .....	RD-25RJ472N
R96	22k .....	RD-25RJ223N
R97 thru		
R99	not used	
R100	3.3k .....	RC-14GK332N
R101 thru		
R110	not used	
R111	2.7k .....	RD-25RJ272N
RV1	10k, semi-fixed resistor .....	RP-GNB10301
RV2	5k semi-fixed resistor .....	RP-GNB50202
RV3	20k semi-fixed resistor .....	RP-GNB20301
RV4	20k semi-fixed resistor .....	RP-GNB20301
SW1	switch rotary .....	SR-194020W
T1	rf transformer .....	TR-10DB002S

Reference Designator	Description	Part No.
T2	rf transformer .....	TR-10MB005S
T3	rf transformer .....	TR-10CB001S
T4	rf transformer .....	TR-10CP005S
T5	rf transformer .....	TR-10MP003T
T6	rf transformer .....	TR-10CA003T
T7	rf transformer .....	TR-07MB008N
T8	if transformer.....	TR-07LA004N
T9	if transformer.....	TR-07LA005N
T10	if transformer.....	TR-07LA023N
T11	audio transformer.....	TB-G25B001W
X1	crystal oscillator 10.24000 MHz .....	XA-S1B9001T
X2	crystal oscillator 10.69500 MHz .....	XA-S1B9002T
Quantity	Description	Part No.
2	crystal spacer.....	VK111SC001
1	heat sink, IC4 .....	ML-454AD002
1	heat sink, IC4 .....	MS-327AD005

### Monitor Receiver P.C. Board

Reference Designator	Description	Part No.
	monitor receiver p.c. board, plated and drilled .....	75A151
C400	.01uF, 25V, ceramic.....	72A440
C401	1uF, 50V, electrolytic .....	72A430
C402	.01uF, 25V, ceramic.....	72A440
C403	.01uF, 25V, ceramic.....	72A440
C404	.01uF, 25V, ceramic.....	72A440
C405	27pF, 50V, ceramic .....	72A404
C406	39pF, 50V, ceramic .....	72A407
C407	.01uF, 25V, ceramic.....	72A440
C408	2pF, 50V, ceramic .....	72A444
C409	.01uF, 25V, ceramic.....	72A440
C410	10pF, 50V, ceramic .....	72A399
C411	330pF, 50V, ceramic .....	72A416
C412	2pF, 50V, ceramic .....	72A444
C413	.047uF, 50V, mylar .....	72A443
C414	.047uF, 50V, mylar .....	72A443
C415	.047uF, 50V, mylar .....	72A443
C416	.047uF, 50V, mylar .....	72A443
C417	.047uF, 50V, mylar .....	72A443
C418	10uF, 16V, electrolytic.....	72A434
C419	3.3uF, 25V, electrolytic .....	72A431
C420	.0047uF, 50V, mylar .....	72A425
C421	.0047uF, 50V, mylar .....	722425
C422	1uF, 50V, electrolytic.....	72A430
C423	33uF, 6.3V, electrolytic .....	72A435
C424	.047uF, 50V, ceramic.....	72A419
C426	.047uF, 50V, ceramic.....	72A419
C427	.047uF, 50V, ceramic.....	72A419

Reference Designator	Description	Part No.
C428	22pF, 50V, ceramic .....	72A403
C429	560pF, 50V, ceramic .....	72A421
C430	68pF, 50V, ceramic .....	72A409
C431	.047uF, 50V, ceramic.....	72A419
C432	.047uF, 50V, ceramic.....	72A419
C433	.047uF, 50V, mylar .....	72A443
C434	.047uF, 50V, mylar .....	72A443
C435	.047uF, 50V, ceramic.....	72A419
C436	3.3uF, 25V, electrolytic .....	72A431
C437	.047uF, 50V, ceramic.....	72A419
C438	.0047uF, 50V, mylar .....	72A425
C439	.047uF, 50V, ceramic.....	72A419
C440	.047uF, 50V, ceramic.....	72A419
C441	.047uF, 50V, ceramic.....	72A419
C442	.047uF, 50V, ceramic.....	72A419
C443	.01uF, 50V, ceramic.....	72A440
C444	.01uF, 50V, ceramic.....	72A440
C445	.01uF, 50V, ceramic.....	72A440
CF401	ceramic filter, 455 kHz .....	78A067
D401	1N4148 .....	76A037
D402	1N4148 .....	76A037
D403	1N4148 .....	76A037
D404	1N4148 .....	76A037
D405	1N60 .....	76A057
D406	1N4148 .....	76A037
IC401	4001, 2 input, NOR IC.....	76A114
IC402	4066, IC multiplexer.....	76A333
L401	rf transformer, 10.7 MHz.....	73A041
Q401	MPS6514 .....	76A140
Q402	MPS6514 .....	76A140
Q403	MPS6513 .....	76A139
Q404	2N5088 .....	76A149
Q405	MPS6514 .....	76A140
Q406	MPS6514 .....	76A140
Q407	MPS5172 .....	76A138
Q408	2N5088 .....	76A149
Q409	MPS5172 .....	76A138
Q410	MPS3702 .....	76A141
Q411	TIP-30 .....	76A319
Q412	MPS6513 .....	76A139

**NOTE:** all resistors 5%, ¼ watt, carbon film unless otherwise noted.

R400	100k .....	72A612
R401	100 .....	72A540
R402	2.2k .....	72A572
R403	680 .....	72A560
R404	1.5k .....	72A568
R405	100 .....	72A540



<b>Reference Designator</b>	<b>Description</b>	<b>Part No.</b>
R406	1.8k .....	72A570
R407	470 .....	72A556
R408	1k .....	72A564
R409	1k .....	72A564
R410	22k .....	72A596
R411	100k .....	72A612
R412	1k .....	72A564
R413	4.7k .....	72A580
R414	470 .....	72A556
R415	47k .....	72A604
R416	1.5k .....	72A568
R417	220 .....	72A548
R418	330 .....	72A552
R419	27k .....	72A598
R420	220 .....	72A548
R421	47 .....	72A532
R422	22k .....	72A596
R423	270k .....	72A622
R424	47k .....	72A604
R425	68k .....	72A608
R426	47k .....	72A604
R427	100k .....	72A612
R428	33k .....	72A600
R429	22k .....	72A596
R430	1.8k .....	72A570
R431	18k .....	72A594
R432	1k .....	72A564
R433	27k .....	72A598
R434	1.5k .....	72A568
R435	5.6k .....	72A582
R436	10k .....	72A588
R437	100k .....	72A612
R438	100 .....	72A540
R439	1k .....	72A564
R440	47 .....	72A532
R441	10k .....	72A588
R442	100k .....	72A612
R443	100 .....	72A540
R444	47 .....	72A532
R445	100 .....	72A540
R446	100 .....	72A540
R447	100k .....	72A612
R448	100 .....	72A540
RV400	10k potentiometer .....	72A398
T401	transformer, 27 MHz .....	73A044
T402	transformer, 27 MHz .....	73A045
T403	transformer, 10.7 MHz .....	73A041
T404	transformer, 455 kHz .....	73A038
T405	transformer, 455 kHz .....	73A039
T406	transformer, 455 kHz .....	73A040
X400	crystal, 16.37 MHz .....	78A076

### LED P.C. Board

Reference Designator	Description	Part No.
	LED p.c. board, complete .....	AP-TLD015AA
	LED p.c. board, plated and drilled .....	PT-LD015AOX
LED	SL122 .....	QL-#SL1222C

### Lamp Control P.C. Board

Reference Designator	Description	Part No.
	lamp control p.c. board, complete .....	AP-TZZ005AA
	lamp control p.c. board, drilled and plated .....	PT-ZZ005AOX
C1	.01uF, 50V, ceramic .....	CK-CB103PEM
C2	.01uF, 50V, ceramic .....	CK-CB103PEM
C3	10uF, 16V, electrolytic .....	CE-ED100ALN
Q1	2SC945ARQ .....	QT-C0945ADA
Q2	2SC945ARQ .....	QT-C0945ADA
Q3	2SC945AR .....	QT-C0945ACA
Q4	2SC945ARQ .....	QT-C0945ADA

**NOTE:** all resistors are 5%, ¼ watt, carbon film unless otherwise noted.

R1	10k .....	RD-14TJ103N
R2	270, ½ W, solid .....	RC-12GK271N
R3	15k .....	RD-14TJ153N
R4	330, ½W, solid .....	RC-12GK331N
R5	330k .....	RD-14TJ334N
R6	100k .....	RD-14TJ104N

### Switch P.C. Board

Reference Designator	Description	Part No.
	switch p.c. board, complete .....	AP-TSW023AA
	switch p.c. board, drilled and plated .....	PT-SW023AOX
	1.8k, 1%, ¼W, resistor array .....	RA-C182M07N

### Chassis Mounted Components

Reference Designator	Description	Part No.
C201	180pF, 500V, mica .....	CM-SD181KCS
C201B	7pF, 500V, ceramic .....	CC-DE070DOM
C202	.01uF, 50V, ceramic .....	CK-CB103PEM
C203	.01uF, 50V, ceramic .....	CK-DB103PEM
C204	.01uF, 50V, ceramic .....	CK-DB103PEM
C205	.047uF, 50V, ceramic .....	CK-DB473ZFM

Reference Designator	Description	Part No.
C206	.01uF, 50V, ceramic	CK-DB103PEM
C207	.01uF, 50V, ceramic	CK-DB103PEM
C208	.0047uF, 50V, ceramic	CK-DB472PEM
C209	.0047uF, 50V, ceramic	CK-DB472PEM
C210	.0047uF, 50V, ceramic	CK-DB472PEM
C211	.0047uF, 50V, ceramic	CK-DB472PEM
C212	.0047uF, 50V, ceramic	CK-DB472PEM
C213	.0047uF, 50V, ceramic	CK-DB472PEM
C214	1 uF, 50V, electrolytic	CE-AG010ALN
J1	jack, 2-pin, antenna	YJ-C02S002Z
J2	jack, 5-pin, DIN, microphone	YJ-D05S001Z
J3	jack, 3-pin, PA	YJ-T03S003Z
J4	jack, 3-pin, external speaker	YJ-T03S003Z
J5	jack, 2-pin, DC	YJ-B02S001U
D201	1N4001 diode	76A076
M/PL3	meter/lamp	ZM-J2030N07
PL1	lamp, monitor	ZP-A064118U
PL2	lamp, transmitter	ZP-A064119U
R201	100k	RD-14TJ104N
S2	switch, toggle	ST020201ZM
S3	switch, rotary	SR-0304103E
VR1, VR3/S1	50k, 100k, potentiometer, ganged (volume, rf gain, on/off switch)	RV-PB104B01
VR2, VR4	10k, 10, potentiometer, ganged (squelch)	RV-PB103B01
	speaker	ZQ-A0920801

### Mechanical Parts

Part Number	Description	Qty
MZ-421SZ003	bracket, meter	1
ML-121SZ007	bracket, speaker	4
MU-276SW002	bracket, mobile mounting	1
MC-473SZ002	bracket p.c. board	1
MU-773SM053	case, top	1
MU-773SM054	case, bottom	1
MU-677SZ049	chassis	1
MX-315SZ001	clamp	1
AC-DC036GEA	cord, power	1
AM-2706#01	excutechon assembly	1
ASM-2683B#01	frame	1
MB-762SZ053	front panel	1
MZ-331SZ002	hanger, microphone	1
VN-176SB006	knob, channel selector	1
VN-274SM001	knob, volume and squelch	2
VN-176SB002	knob, rf gain, switch	2
VN-276SB008	knob, CB-PA	1

### Accessory Parts

<b>Part Number</b>	<b>Description</b>	<b>Qty</b>
BT-PT5013AN	screw, truss head tapping, unit mounting M5x13 .....	4
BT-PP4010BZ	screw, pan head tapping, unit mounting M4x10 .....	2
MF-284SN001	thumb screw .....	2

**HY-GAIN DE PUERTO RICO, INC.**

**P.O. Box 68 State Hwy 31, Km. 4.0  
Naguabo, Puerto Rico 00718**




Figure 2-2. Block Diagram, CB Transceiver




Figure 2-3. Block Diagram, Monitor Receiver




Figure 4-5. Schematic Diagram, Model 2706